



C3030-7

Datumovka - Den + měsíc + rok (kombinace tří)



* Parametr "a" udává hloubku šipky ve vložce datumovky.



| kód | rok | D | L | d | a* | M | T |
|---------------|-----|----|----|---|-----|----|---|
| C3030-7/5/24 | 24 | 5 | 17 | 3 | 0,4 | M3 | 3 |
| C3030-7/5/25 | 25 | 5 | 17 | 3 | 0,4 | M3 | 3 |
| C3030-7/6/24 | 24 | 6 | 17 | 3 | 0,4 | M3 | 3 |
| C3030-7/6/25 | 25 | 6 | 17 | 3 | 0,4 | M3 | 3 |
| C3030-7/8/24 | 24 | 8 | 20 | 4 | 0,4 | M4 | 5 |
| C3030-7/8/25 | 25 | 8 | 20 | 4 | 0,4 | M4 | 5 |
| C3030-7/10/24 | 24 | 10 | 20 | 5 | 0,4 | M5 | 5 |
| C3030-7/10/25 | 25 | 10 | 20 | 5 | 0,4 | M5 | 5 |
| C3030-7/12/24 | 24 | 12 | 25 | 6 | 0,6 | M6 | 6 |
| C3030-7/12/25 | 25 | 12 | 25 | 6 | 0,6 | M6 | 6 |