


# C3031-1

## Datumovka - Měsíc + rok



\* Parametr "a" udává hloubku šipky ve vložce datumovky.



kód	rok	D	L	d	a*	M	SW
C3031-1/5/26	26	5	17	3	0,4	M3	2
C3031-1/6/26	26	6	17	3	0,4	M3	2
C3031-1/8/26	26	8	20	4	0,4	M4	3
C3031-1/10/26	26	10	20	5	0,4	M5	3
C3031-1/12/26	26	12	25	6	0,6	M6	4