


# C3031-2

## Datumovka - Měsíce



\* Parametr "a" udává hloubku šipky ve vložce datumovky.



| kód               | D  | L  | d | a*  | M  | SW |
|-------------------|----|----|---|-----|----|----|
| <b>C3031-2/5</b>  | 5  | 17 | 3 | 0,4 | M3 | 2  |
| <b>C3031-2/6</b>  | 6  | 17 | 3 | 0,4 | M3 | 2  |
| <b>C3031-2/8</b>  | 8  | 20 | 4 | 0,4 | M4 | 3  |
| <b>C3031-2/10</b> | 10 | 20 | 5 | 0,4 | M5 | 3  |
| <b>C3031-2/12</b> | 12 | 25 | 6 | 0,6 | M6 | 4  |